

Perfect fit:

A guide to adjusting your kid's Arcade straps

Our Arcade sandals are **designed with adjustability in mind, catering to different foot shapes and sizes**. If your child has narrow or low-volume feet, the straps may extend beyond the necessary length, causing them to curl at the edges. To ensure a secure and comfortable fit, the strap tips can be trimmed.

Each strap on the Arcade shoes features two thin channels without seams. These channels indicate where you can cut with scissors to adjust the length. This manual will provide you with step-by-step instructions to help you personalize the strap length for a perfect fit.



Measure and mark



1. Have your child wear the shoes and fasten the straps to a comfortable tightness.



2. Identify where the excess strap extends beyond the velcro attached to the upper.



3. Mark the correct channel using a pencil, starting with a conservative trim – less than you think is necessary, as you can always cut more later.

Cut the straps



1. Unfasten the straps and remove the shoes from your child's feet.

2. Using the marked line as a guide, carefully cut along the thin channel with scissors.

Check the fit



1. Adjust if necessary. If the strap is still too long, repeat the marking and cutting process, trimming a bit more as needed.

2. Ensure all straps are evenly cut and even out any rough edges.

Prevent fraying



1. To prevent fraying, apply a thin layer of textile glue along the open edge of each strap.

2. Press the edges down gently and let the glue dry completely for a clean, durable finish.

Thank you for choosing Arcade shoes. We hope they provide the perfect fit and comfort for your child's adventures!